



Tack weld sensor jigs in position on draw bar and axles

Insert sensors as per instruction detail



Set the sensor outputs as recommended

Once sensors are set, attach the covers



Enter the empty and loaded weights into the external bluetooth display to calibrate

The SmartWeigh kit is fitted and ready for use

