



SMARTWEIGH

INTELLIGENT VEHICLE WEIGHING




Tanker / Trailer Calibration

Download the app from inside the lid

CONTACT US:




+44 (0)1603 485 153



Before You Begin

- Use a level weighbridge.
- Download the app Right Weigh Load Scales from the App Store or Google Play (used for remote load monitoring).
- ⚠ Important: When weighing, always place the trailer only on the weighbridge—do not leave it attached to the tractor unit during calibration.



Step 1 Weigh the Empty Trailer (Tare Weight)

Turn on the scale by pressing the ON/OFF button.



Step 2

Drop the **EMPTY** trailer on the weighbridge

- Unhook the tractor/trailer. It must be **completely disconnected**.
- Ensure the trailer is level.
- Record the weight shown on the weighbridge (this is your **empty weight**).

Step 3 Set the Empty (Tare) Weight on the scale

A) Enter **EMPTY** calibration mode

- Press and hold the **C LOW** (2) button until **C/L** appears on the screen.

B) Input the empty weight



- Use the **UP** (4) and **DOWN** (3) buttons to enter the weight from the weighbridge.

C) Save it

- Press and hold the **C LOW** (2) button again until **C/L** disappears.



✓ Your empty trailer is now stored.



Step 4 Weigh the Loaded Trailer

Load the trailer with product as normal.

Step 5

Drop the LOADED trailer on the weighbridge

- Again, make sure it is not connected to the trailer unit.
- Confirm the trailer is level.
- Record the full (loaded) weight.

Step 6 Set the Loaded Weight on the scale

A) Turn on the scale (if its off).

- Press the **ON/OFF** button

B) Enter LOADED calibration mode.

- Press and hold the **C HIGH** button until **C/H** appears on screen.

C) Input the loaded weight.




- Use the **UP** (4) and **DOWN** (3) buttons to enter the full trailer weight.

D) Save it

- Press and hold the **C HIGH** (1) button again until **C/H** disappears.



✓ You have now calibrated the loaded weight.



Final Tips

- Calibrate and weigh only when the **trailer is level** and **not attached to the tractor**.
- The system is for **guidance only**, not certified for legal trade.
- Use the **Right Weigh Load Scales** app to monitor loads from your phone or tablet.